

**ODOURLITE UNDERCOAT**
*Updated Aug'16*


Odourlite Undercoat is a low odour oil modified alkyd based undercoat with non-added lead and chrome. It provides a sound foundation for Odourlite Gloss Finish and Odourlite Soft Matt Finish to give good hiding and build.

**Product Features:**

- No added lead or mercury

Paint Type	Product Type	Finishing	Recommended Substrate	Pack Size
Solvent based	Interior & Exterior	Matt	Wood and Metal	1 Litre, 5 Litres

**Composition**

Pigment	: Titanium dioxide and mineral extenders
Binder	: Modified long oil alkyd
Thinner	: De-aromatised hydrocarbon

**Technical Data**

Drying Time	: Touch Dry : 30 minutes (Dependent on temperature and humidity)
	: Hard Dry : 6 hours (Dependent on temperature and humidity)
Recoating Time	: 8 hours (Dependent on temperature and humidity)
Dry Film Thickness	: Around 30 µm per coat (based on substrate condition)
No. of Coats	: 1 coat
Theoretical Coverage	: 9 – 11 m <sup>2</sup> per litre per coat (Actual coverage is dependent on substrate condition, application method, application condition and finishing appearance)
Volume Solid	: ~ 49%
Shelf Life	: Up to 36 months in tight sealed container

**Application Method**

Brush / Roller	: The paint is ready for use after thorough stirring. If necessary, thin with 5% of Odourlite Thinner.
Conventional Air Spray	: Dilute the paint with not more than 15 – 20 % of Odourlite Thinner.

**Recommended Coating System**
**Wood**

Undercoat	: Odourlite Undercoat	: 1 Coat
Top Coat	: Odourlite Gloss Finish / Odourlite Soft Matt Finish	: 2 Coats

**Metal**

Primer / Sealer	: Red Oxide Primer	: 1 Coat
Undercoat	: Odourlite Undercoat	: 1 Coat
Top Coat	: Odourlite Gloss Finish / Odourlite Soft Matt Finish	: 2 Coats

**Surface Preparation**
**Wood**

Surface must be dry and free from dirt, grease and other contaminants. Smoothen surface with sandpaper and then clean off and dry. The scraped areas should be spot-primed using an undercoat for wood surfaces. Light sanding on surface would ensure better subsequent intercoat adhesion.

**Metal**

Surface must be dry and free from dirt, grease and other contaminants. Ferrous substrate should be sanded or wire-brushed to remove millscalls and rust. Clean off dust and dry. The scraped areas should be spot-primed using a primer for metal. Light sanding on surface would ensure better subsequent intercoat adhesion.

**Cleaning**

Clean up equipment with water immediately after use.

**Safety Precautions**

- Keep container tightly closed and keep out of reach children or away from food and drink.
- Ensure good Ventilation during application and drying.
- When applying paint, it is advisable to wear eye protection.
- In case of contact with eye, rinse with plenty of water immediately and seek medical advice.
- Remove splashes from skin by using soap or water.
- Paint must always be stored in a cool place.
- When transporting paint, care must be taken. Always keep container in a secure upright position.
- Dispose off any paint waste in accordance with the appropriate Environment Quality Regulations.

**Note**

\* Theoretical Coverage is based on a mathematical formula

$$\left[ \frac{\text{Volume Solid \%} \times 10}{\text{Dry Film Thickness}} \right] = \text{m}^2/\text{lit}/\text{coat}$$

and does not consider LOSS FACTORS.

Variables like porosity of substrate, application method, dilution ratio, dry film thickness, opacity and so on will affect the loss factor and can vary from 30% - 50% or even more.

The above information is given to the best of our knowledge based on laboratory tests and practical experience.

However, since we cannot anticipate or control the many conditions under which our products may be used, we can only guarantee the quality of the product itself.

We reserve the right to alter the given without prior notice.